

# DAVE Extract DE-ES

## Extract Fans with Ecosmart Control

### Installation and Maintenance Manual



## 1.0 IMPORTANT SAFETY INFORMATION

- The provision of the electrical supply and the connection of the unit to the electrical supply must be carried out by a qualified electrician.
- Isolate from power supply before removing any covers. During installation / maintenance ensure all covers are fitted before switching on the mains supply.
- All-pole disconnection from the mains as shown in the wiring diagram must be incorporated within the fixed wiring and shall have a minimum contact separation of 3mm in accordance with latest edition of the wiring regulations.
- This unit must be earthed.
- Ducting must be securely fixed with screws to the spigot to prevent access to live parts. Duct runs terminating close to the fan must be adequately protected by suitable guards.
- This appliance should not be used by children or persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge, unless they have been given supervision or instruction concerning the safe use of the appliance by a person responsible for their safety. Children shall not play with the appliance. Cleaning and user maintenance shall not be carried out by children.

## 1.1 HAZARD SYMBOLS



### GENERAL WARNING

Signifies a general warning regarding hazard specified by supplementary information.



### ELECTRIC SHOCK

This unit must be completely electrically isolated before any panels are removed. Check mains supply and control connections.



### ROTATING PARTS

This unit contains fast moving rotational parts which may start automatically. It is the sole responsibility of the installer to adequately guard these components.



### REFER TO INSTRUCTION MANUAL

Read and understand the installation and maintenance manual before installing, operating or maintaining this product.

## 1.2 IMPORTANT INFORMATION

This manual contains important information on the safe and appropriate assembly, transport, commissioning, operation, maintenance, disassembly and simple troubleshooting of the product.

While the product has been manufactured according to the accepted rules of current technology, there is still a danger of personal injury or damage to equipment if the following general safety instructions and the warnings contained in these instructions are not complied with.

- **Read these instructions completely and thoroughly before working with the product.**
- **Keep these instructions in a location where they are accessible to all users at all times.**
- **Always include the operating instructions when you pass the product on to third parties.**

## 1.3 PERSONAL PROTECTIVE EQUIPMENT

The following minimum Personal Protective Equipment (PPE) is recommended when interacting with Nuaire product:

- **Protective Steel Toed Shoes** - when handling heavy objects.
- **Full Finger Gloves (Marigold PU800 or equivalent)** - when handling sheet metal components.
- **Semi Fingerless Gloves (Marigold PU3000 3DO or equivalent)** - when conducting light work on the unit requiring tactile dexterity.
- **Safety Glasses** - when conducting any cleaning/cutting operation or exchanging filters.
- **Reusable Half Mask Respirators** - when replacing filters which have been in contact with normal room or environmental air.

Nuaire would always recommend a site specific risk assessment by a competent person to determine if any additional PPE is required.

## 2.0 INTRODUCTION

The Dave range of in-line backward curve fans consists of 9 sizes with a maximum duty of 1.1m<sup>3</sup>/s (1100l/s).

Units are manufactured from aluzinc, rectangular in section and have circular rigid spigots at each end. All units are supplied with fixing brackets designed to simplify installation.

### 2.1 CODE DESCRIPTION:

1	2	3	4	5	-	6	7	8
DE	2	1	H	A	-	ES	H	-C4

- 1. Range: **DE** = Dave Extract
- 2. Unit Size: **1-7**
- 3. Blower Reference: **Office-use only**
- 4. Fan Type: [none] = Standard Fan  
**H** = High Pressure Fan
- 5. Case Type: [none] = Standard case, no attenuation.  
**A** = Extended case with integral attenuation pods and G3 Panel Filter
- 6. Control Type **ES** = Ecosmart Classic Control
- 7. Electrical Frequency [none] = 50Hz  
**H** = 60Hz
- 8. Protection [none] = Standard Magnelis Finish  
**-C4** = C4 Coastal Paint Protection

## 3.0 DELIVERY & HANDLING

All equipment is inspected prior to despatch and leaves the factory in good condition. Upon receipt of the equipment an inspection should be made and any damage indicated on the delivery note.

Particulars of damage and/or incomplete delivery should be endorsed by the driver delivering the goods before offloading by the purchaser.

No responsibility will be accepted for damage sustained during the offloading from the vehicle or on the site thereafter.

All claims for damage and/or incomplete delivery must be reported to Nuair within two days of receipt of the equipment.


### 3.1 OFFLOADING & HANDLING

The weight of the unit modules and palletised items are displayed on the packaging.

Some of the modules have an uneven weight distribution, and this will be indicated by labelling where appropriate.


Offloading and positioning of the equipment is the responsibility of the purchaser. Items should only be lifted by competent personnel following appropriate risk assessment.

Fig 1: Lifting Methods



## 4.0 DIMENSIONS (mm) & WEIGHTS (kg)

Fig 2: Dimensions



Removable weatherproof control cover dimensions:  
470mm (w) x 173mm (h) x 120mm (d)

Code	A	B	C	D 'DIA'	G	H	J	K	L	(kg)
DE1*	605	567	237	150	370	150	100	560	609	25
DE1A*	1004	567	237	150	370	150	100	960	609	30
DE2*	605	703	304	200	370	150	100	560	746	25
DE2A*	1004	703	304	200	370	150	100	960	746	40
DE3*	605	788	349	200	370	150	100	560	830	30
DE3A*	1004	788	349	200	370	150	100	960	830	50
DE4*	605	848	374	250	370	150	100	560	890	35
DE4A*	1004	848	374	250	370	150	100	960	890	67
DE5*	605	992	414	315	370	150	100	560	1034	59
DE5A*	1004	992	414	315	370	150	100	960	1034	70
DE6*	605	1100	459	400	370	150	100	560	1142	69
DE6A*	1004	1100	459	400	370	150	100	960	1142	75
DE7*	605	1208	504	400	370	150	100	560	1250	82
DE7A*	1004	1208	504	400	370	150	100	960	1250	90

\*Denotes any suffix

### 5.0 MECHANICAL INSTALLATION


Installation must be completed by competent persons, in accordance with good industry practice and should conform to all governing and statutory bodies i.e. IEE, CIBSE, etc.

**Service / Maintenance Access – Unit must be installed with a minimum of unit depth as additional clearance i.e. DS1A-NES either allow 233mm above or below unit.**

**Access to the unit for maintenance is via the top or bottom lid, this should be taken into account before installation takes place (see important note).**

Dave extract fans can be installed in any orientation. Units are supplied complete with four support mounting brackets for quick and easy installation, either surface mounted or suspended with drop rods.

Fig 3: Unit Mounting Bracket (M8)



### 6.0 ELECTRICAL INSTALLATION

**Isolation - Before commencing work, make sure that the unit and Nuair control are electrically isolated from the mains supply.**

#### 6.1 UNIT DETAILS

Unit details including Full Load Current, Voltage, fan speed etc. can be found on the unit label.

#### 6.2 WIRING DIAGRAMS

**Local isolator (by others).** All inter-connections between circuit boards, blowers and sensors are made at the factory. Remove link wire if switched live signal, an enabler or BMS signal is connected.

Fig 4: Wiring Diagram DE1-7 with Standard Case and No Filter





Fig 5: Wiring Diagram DE1-7 with Extended Case and Filter



6.3 ELECTRICAL CONNECTIONS


6.3.1 MAINS CONNECTIONS

Mains cables should be suitably sized and terminated at the terminals shown on the appropriate diagram.

6.3.2 CONTROL CONNECTIONS

3 IDC plug-in Net connectors are provided for the connection of compatible sensors, manual controls and for linking the fans together under a common control. If more than 3 connections are required, the junction box (product code **ES-JB**) should be used (see data cable installation).

Fig 6: Ecosmart Net Connections



6.3.3 MAXIMUM NUMBER OF DEVICES


6.3.4 The maximum number of devices (including fans) that can be connected together via the cable is 32, irrespective of their functions.

6.3.5 SWITCHED LIVE (SL) TERMINAL

Mains cables should be suitably sized and terminated at the terminals shown on the appropriate diagram.

Fig 7: SL Terminal

Remove link if switched live signal, an enabler or BMS signal is connected.



Mains connection pre-wired  
230V 50Hz 1ph / 220V 60Hz 1ph


A signal of 100-230V / 220V a.c. will activate the fan from either its off state or trickle state (see setting to work-trickle switch). When the SL is disconnected the fan will over-run (see setting to work-timer adjustment). **Do not take this signal from an isolating transformer.**

6.3.7 VOLT FREE RELAY CONTACTS

Volt free contacts are not fused, if these are used to power any external equipment, the installer must provide adequate fusing or other protection. These contacts are rated at 5A resistive, 0.5A inductive.

**Run Connections** = Contacts are closed when the fan is running.  
**Fault Connections - No Fault** = Contacts are closed.  
**Fault Connections - Fault** = Contacts are open.

Fig 8: Volt Free Relay Contacts



6.3.8 DATA CABLE INSTALLATION

A 4-core SELV data cable is used to connect devices. Do not run data cable in the same conduit as the mains cables and ensure there is a 50mm separation between the data cable and other cables. The maximum cable run between any two devices is 300m when it is installed in accordance with the instructions.


**Please note that the total data cable length used in any system must be less than 1000m. Keep the number of cable joints to a minimum to ensure the best data transmission efficiency between devices.**

6.3.9 OTHER LOW VOLTAGE CABLES

Follow the basic principle (as 5.1.6). Keep the cable run as short as possible, less than 50 metres.

6.3.10 COMMISSIONING PANEL DETAILS

A Commissioning Procedure document (leaflet No. 671153) is available on request from the Nuair Technical Library, Tel: 029 2088 5911.




6.4 LED INDICATOR

LED	Description
PWR	GREEN: Power on & OK. RED: Too much power is taken by peripherals or there is a short circuit in the net cable. Check the cable and use a junction box (ES-JB) to connect some of the peripherals
Standby	LED on when fan is not running
Fan 1	GREEN: Fan is running RED: Fan is faulty
Fan 2*	n/a
Heating*	n/a
Cooling*	n/a
Fault*	n/a
Frost*	n/a
TX	LED on when the controller is transmitting data.
RX	LED on when the controller is transmitting data.

\*The control panel is common to all the Ecosmart classic products and will have indicators for functions that are not available in this particular fan. However these indicators will not be illuminated.

6.5 CONTROL PANEL




6.5.1 BMS INPUT SIGNALS

The BMS connection is made with a plug-in connector via the socket. To ensure the connection is made only by suitably qualified and authorised personnel the plug is not supplied.

Plug-in BMS connector is available from: **R S Components, Part No. 176-7772**

Fig 11: BMS Connection



Reversal of the BMS connection will damage the control.

The system's response to a 0-10V dc BMS signal is given in the table below.

Note the BMS signal will override any sensors and user control connected in the system. The voltage tolerance is +/- 125mV and is measured at the fans terminal.

Fan Speed	Ventilation	Cooling Mode*	Heating Mode*
Local Control	0.00	-	-
OFF / Trickle	0.25	-	-
Speed 1	0.50	0.75	1.00
Speed 2	1.50	1.75	2.00
Speed 3	2.50	2.75	3.00
Speed 4	3.50	3.75	4.00
Speed 5	4.50	4.75	5.00
Speed 6	5.50	5.75	6.00
Speed 7	6.50	6.75	7.00
Speed 8	7.50	7.75	8.00
Speed 9	8.50	8.75	9.00
Speed 10	9.50	9.75	10.00

\* Not applicable to Dave extract fans

7.0 MAINTENANCE

Isolation - Before commencing work, make sure that the unit and Nuair control are electrically isolated from the mains supply.

It is important that maintenance checks are recorded and that the schedule is always adhered to, in all cases, the previous report should be referred to.

Motors are fitted with sealed for life bearings and do not require any lubrication.

7.1 ROUTINE MAINTENANCE

- Remove the top or the bottom cover and carefully clean out the interior as necessary.
- Check all parts for security and that the impeller rotates freely, taking care not to disturb the balance.
- The filter (where applicable) will require cleaning on a regular basis. The frequency of the cleaning operation will depend on the site conditions.
- Ensure all control components are secure and clean.
- Refit the cover.

**7.2 ANNUALLY**

- All electrical terminals within the unit should be tightened.
- Check all earth connections.

**7.3 DIRTY FILTER ALARM (EXTENDED CASE MODELS ONLY)**

Units pre fitted with a panel air filter are equipped with an visual Red LED alarm on the side of the control. The pressure switch is pre set at 150pa and positioned within the unit and accessed via the removable top or bottom panel. If required, the alarm signal can be positioned to another area by others using the pre fitted terminal block - A volt free relay must be used between the control and customer wiring.


**LED On** = Pressure exceeds the max allowable final pressure drop.

**7.4 G3 FILTER REPLACEMENT (EXTENDED CASE MODELS ONLY)**

Code	Replacement Part Number
DE1A-ES	D1A-G3FILTERKIT
DE2A-ES	D2A-G3FILTERKIT
DE2HA-ES	D2HA-G3FILTERKIT
DE3A-ES	D3A-G3FILTERKIT
DE4A-ES	D4A-G3FILTERKIT
DE4HA-ES	D4HA-G3FILTERKIT
DE5A-ES	D5A-G3FILTERKIT
DE6A-ES	D6A-G3FILTERKIT
DE7A-ES	D7A-G3FILTERKIT

**7.5 UNIT COMPONENTS**

**Fig 12: Exploded View Diagram**



Letter	Component
A	Lid/Base
B	Attenuation Pods (Extended case 'A' models only)
C	Attenuation Pod Retaining Clips ('A' models only)
D	G3 panel Filter (Extended case 'A' models only)
E	Weather Cover for Control Box (use if required)

**8.0 WARRANTY**

The 5 year warranty starts from the day of delivery and includes parts and labour for the first year. The remaining period covers replacement parts only.

This warranty is void if the equipment is modified without authorisation, is incorrectly applied, misused, disassembled, or not installed, commissioned and maintained in accordance with the details contained in this manual and general good practice.

The product warranty applies to the UK mainland and in accordance with Clause 14 of our Conditions of Sale. Customers purchasing from outside of the UK should contact Nuair International Sales office for further details.

**Failure to maintain the unit as recommended will invalidate the warranty.**

**9.0 END-OF-LIFE AND RECYCLING**

**Ensure that Nuair product is made safe from any electrical / water / refrigerant supplies before dismantling commences. This work should only be undertaken by a qualified person in accordance with local authority regulations and guidelines, taking into account all site based risks.**

Where possible Nuair use components which can be largely recycled when the product reaches its end-of-life:

- Fans, motors, controls, actuators, cabling and other electrical components can be segregated into WEEE recycling streams.
- Sheet metal parts, aluminium extrusion, heating/cooling coils and other metallic items can be segregated and fully recycled.
- EPP, plastic ducting, nylon corner pieces, plastic heat exchangers, packaging material and other plastic components can be segregated into mixed plastic and widely recycled.
- Cardboard packaging, wood, used filters and other paper components can be largely recycled or fully processed in energy from waste centres.
- Remaining Items can be further segregated and processed in accordance with the zero waste hierarchy. Please call After Sales Support for further information on items not listed above.

**10.0 AFTER SALES AND REPLACEMENT PARTS**

For technical assistance or further product information, including spare parts and replacement components, please contact the After Sales Department.

If ordering spares please quote the serial number of the unit together with the part number, if the part number is not known please give a full description of the part required. The serial number will be found on the identification plate attached to the unit casing.

**Telephone 02920 858 400**  
**aftersales@nuaire.co.uk**

Technical or commercial considerations may, from time to time, make it necessary to alter the design, performance and dimensions of equipment and the right is reserved to make such changes without prior notice.





## DECLARATION OF INCORPORATION AND INFORMATION FOR SAFE INSTALLATION, OPERATION AND MAINTENANCE

We declare that the machinery named below is intended to be assembled with other components to constitute a system of machinery. All parts except for moving parts requiring the correct installation of safety guards comply with the essential requirements of the Machinery Directive. The machinery shall not be put into service until the system has been declared to be in conformity with the provisions of the EC Machinery Directive.

### Signature of manufacture representatives:

Name:	Position:	Date:
1) C. Biggs 	Technical Director	28. 01. 15
2) A. Jones 	Manufacturing Director	28. 01. 15

**Designation of machinery:** DAVE Ecosmart (ES) models  
**Machinery Types:** Extract fans  
**Relevant EC Council Directives:** 20006/42/EC (Machinery Directive)  
**Applied Harmonised Standards:** BS EN ISO 12100, BS EN ISO 13857  
 EN60204-1, BS EN ISO 9001  
**Applied National Standards:** BS4848 Parts 1, 2.2 and 5

Note: All standards used were current and valid at the date of signature.

## INFORMATION FOR SAFE INSTALLATION, OPERATION AND MAINTENANCE OF NUAIRE VENTILATION EQUIPMENT

To comply with EC Council Directives 2006/42/EC Machinery Directive and 2014/30/EU (EMC).  
 To be read in conjunction with the relevant product documentation (see 2.1)

### 1.0 GENERAL

1.1 The equipment referred to in this Declaration of Incorporation is supplied by Nuairé to be assembled into a ventilation system which may or may not include additional components. The entire system must be considered for safety purposes and it is the responsibility of the installer to ensure that all of the equipment is installed in compliance with the manufacturers recommendations and with due regard to current legislation and codes of practice.

### 2.0 INFORMATION SUPPLIED WITH THE EQUIPMENT

2.1 Each item of equipment is supplied with a set of documentation which provides the information required for the safe installation and maintenance of the equipment. This may be in the form of a Data sheet and/or Installation and Maintenance instruction.  
 2.2 Each unit has a rating plate attached to its outer casing. The rating plate provides essential data relating to the equipment such as serial number, unit code and electrical data. Any further data that may be required will be found in the documentation. If any item is unclear or more information is required, contact Nuairé.  
 2.3 Where warning labels or notices are attached to the unit the instructions given must be adhered to.

### 3.0 TRANSPORTATION, HANDLING AND STORAGE

3.1 Care must be taken at all times to prevent damage to the equipment. Note that shock to the unit may result in the balance of the impeller being affected.  
 3.2 When handling the equipment, care should be taken with corners and edges and that the weight distribution within the unit is considered. Lifting gear such as slings or ropes must be arranged so as not to bear on the casing.  
 3.3 Equipment stored on site prior to installation should be protected from the weather and steps taken to prevent ingress of contaminants.

### 4.0 OPERATIONAL LIMITS

4.1 It is important that the specified operational limits for the equipment are adhered to e.g. operational air temperature, air borne contaminants and unit orientation.  
 4.2 Where installation accessories are supplied with the specified equipment e.g. wall mounting brackets. They are to be used to support the equipment only. Other system components must have separate provision for support.  
 4.3 Flanges and connection spigots are provided for the purpose of joining to duct work systems. They must not be used to support the ductwork.  
 4.4 **Local Environment - Humidity.** Ambient humidity (the humidity at the unit's installed location) shall be within the range: 10 to 95% (for controls, non-condensing). Air humidity (the humidity of the air passing through the unit) shall be within the range: 10 to 95% (for controls, non-condensing).

### 5.0 INSTALLATION REQUIREMENTS

In addition to the particular requirements given for the individual product, the following general requirements should be noted.  
 5.1 Where access to any part of equipment which moves, or can become electrically live are not prevented by the equipment panels or by fixed installation detail (e.g. ducting), then guarding to the appropriate standard must be fitted.  
 5.2 The electrical installation of the equipment must comply with the requirements of the relevant local electrical safety regulations.  
 5.3 For EMC all control and sensor cables should not be placed within 50mm or on the same metal cable tray as 230V switched live, lighting or power cables and any cables not intended for use with this product.

### 6.0 COMMISSIONING REQUIREMENTS

6.1 General pre-commissioning checks relevant to safe operation consist of the following:  
 Ensure that no foreign bodies are present within the fan or casing.  
 Check electrical safety e.g. Insulation and earthing.  
 Check guarding of system.  
 Check operation of Isolators/Controls.  
 Check fastenings for security.  
 6.2 Other commissioning requirements are given in the relevant product documentation.

### 7.0 OPERATIONAL REQUIREMENTS

7.1 Equipment access panels must be in place at all times during operation of the unit, and must be secured with the original fastenings.  
 7.2 If failure of the equipment occurs or is suspected then it should be taken out of service until a competent person can effect repair or examination. (Note that certain ranges of equipment are designed to detect and compensate for fan failure).

### 8.0 MAINTENANCE REQUIREMENTS

8.1 Specific maintenance requirements are given in the relevant product documentation.  
 8.2 It is important that the correct tools are used for the various tasks required.  
 8.3 If the access panels are to be removed for any reason the electrical supply to the unit must be isolated.  
 8.4 A minimum period of two minutes should be allowed after electrical disconnection before access panels are removed. This will allow the impeller to come to rest. **NB: Care should still be taken however since airflow generated at some other point in the system can cause the impeller to "windmill" even when power is not present.**  
 8.5 Care should be taken when removing and storing access panels in windy conditions.